

nora[®] MAINTENANCE GUIDE – RAISED ACCESS

General Remarks

nora[®] floor coverings have a natural sheen; therefore they do not require any artificial coating. However, for customers who prefer a high shine, we can recommend alternative maintenance methods that will generate an increase in shine.

General Precautions

1. Always use “wet floor” signs and/or caution tape when performing any wet cleaning.
2. Refer to SDS for proper personal protection requirements before using cleaning products.
3. Do not floor the floor.
4. The floor will be slippery when wet or contaminated with foreign materials. Promptly clean-up spills and any foreign materials to maintain the flooring's slip resistant properties.
5. Never use grit brushes, black or brown cleaning pads.
6. Use a 3M[™] #5100 (Red) cleaning pad when required.
7. Make sure to maintain a good walk-off area in the entrance of the facility, in addition to regular dust mopping.
8. Spots from petroleum-based products such as grease and tar must be removed with spotting agents containing solvents. Immediately rinse with water after spot removing and allow to dry.
9. To increase the shine, the floor can be dry buffed using a 3M[™] #4100 (White) pad.
10. Do not allow any metal furniture or trash cans to be in contact with the wet floor.

1 Post-Installation Maintenance

Note: A general cleaning should be performed a minimum of 72 hours after installation.

The following procedures should be performed by the facility:

1. Dust mop or vacuum the floor to remove dirt or grit.
2. Remove any adhesive residue and/or spots of foreign material using Windex[®] or Goof Off[®] solvent.
3. Using a spray bottle with a diluted initial maintenance product, spray-clean the floor using a 3M[™] #5100 (Red) cleaning pad. Spray the floor every two feet and buff until the floor begins to dry (rinse or change the pad once it is loaded).
4. Damp mop/rinse the floor using a microfiber mop or auto-scrub the floor using a microfiber pad and a minimum amount of clean water, and allow to dry.

Note: To increase the shine, the floor can be dry buffed using a 3M[™] #4100 (White) pad.

Note: Areas where nora[®] liquid wax is used for cold welding, scrub first with a 3M[™] #5300 (Blue) cleaning pad (noraplan[®]) using a high pH cleaner (12-13pH). Pick up residue with a wet vacuum and rinse with water.

2 Daily Maintenance

1. Dust mop or vacuum the floor to remove dust and dirt.
2. Damp mop the floor using a microfiber mop or auto-scrub the floor using a microfiber pad and a minimum amount of a diluted daily maintenance product, and allow to dry.

Note: If required, perform another initial maintenance procedure to remove any dirt build-up.

Updated: 04/2018