

Stain table for dried-out medications

Medical substances are frequently the cause of stains on floor coverings. Stains will not appear if the substances listed in the table below are removed from the flooring straight away. They can only develop if the media are allowed to dry out. Treating stains can cause fading in the affected places and is usually the result of using higher concentrations of mop-care products after spillages. Depending upon the number and size of the stains, once they have been removed it may be advisable to clean the entire floor followed by a care treatment to assure a uniform overall appearance. This should be done using special cleaners by following the instructions in the technical leaflet. Change the exposure times according to the age and intensity of the stain. An unpleasant odour may be given off when cleaning large areas.

Type of stain	Cleaning agent	Removal
Infusion solutions	Diaphragm cleaner, Drak Aquaristik	See instructions in the technical leaflet. May give off an unpleasant odour when cleaning large areas.
Dopamin	Phosphoric acid-based sanitary cleaner (new stains)	Exposure time: 5 - 10 minutes.
	Dismozon pur	See instructions in the technical leaflet. May give off an unpleasant odour when cleaning large areas.
	Apesin AP 100	See instructions in the technical leaflet. May give off an unpleasant odour when cleaning large areas.
Eosin G	Diaphragm cleaner, Drak Aquaristik	See instructions in the technical leaflet. May give off an unpleasant odour when cleaning large areas.
	Special cleaner TAM**	See instructions in the technical leaflet. May give off an unpleasant odour when cleaning large areas.
	Dismozon pur	See instructions in the technical leaflet. May give off an unpleasant odour when cleaning large areas.
Iodine-containing non-dyed products: Betaisodona Braunol Mercuchrom	Iodine removal set* (nora systems)	See instructions in the technical leaflet.
Methyl violet	Special cleaner TAM**	Complete removal not possible. See instructions in the technical leaflet. May give off an unpleasant odour when cleaning large areas.
Rivanol Silver nitrate	Diaphragm cleaner, Drak Aquaristik	Exposure time 10 - 60 minutes depending on the age of the stain. See instructions in the technical leaflet. May give off an unpleasant odour when cleaning large areas.
Dyed iodine-containing and other dyed products: Cutasept G Octenisept G Skinsept G Braunoderm G Disulphine Blue Kodan	Dismozon pur	Exposure time: approx. 15 minutes.
	Apesin AP 100	Exposure time: approx. 15 minutes.
	Iodine removal set* (nora systems)	See instructions in the technical leaflet.
	Special cleaner TAM**	See instructions in the technical leaflet. May give off an unpleasant odour when cleaning large areas.

* Source Iodine removal set: nora systems GmbH, info@nora.com

** Source special cleaner TAM: Carl Roth GmbH + Co. KG, Schoemperlenstr. 1-5, 76185 Karlsruhe, www.carlroth.com
Comp. A: <https://www.carlroth.com/en/en/a-to-z/hydrogen-peroxide/p/9681.1>
Comp. B: <https://www.carlroth.com/en/en/a-to-z/sodium-hydroxide-solution/p/4357.1>