







| | | | |
|------------------|---|---|--|
| <p>1.</p> | <p>Initial cleaning after installation</p> |  <p>Remove dry, loose dirt with a suitable procedure.</p> |  <p>Make sure you spray a suitable cleaning agent (see Cleaning and polishing agents table) using a red pad*.</p> |
| <p>2.</p> | <p>Routine cleaning/ polishing</p> |  <p>Damp-wipe with a spray-dampened or prepared cleaning cloth (gauze cloths).</p> |  <p>If wipe polish products (see Cleaning and polishing agents table) are used, polishing** as needed at periodic intervals using a suitable white polishing pad* is recommended.</p> |
| <p>3.</p> | <p>Intermediate cleaning</p> |  <p>Remove dry, loose dirt with a suitable procedure.</p> |  <p>Make sure you spray a suitable cleaning agent (see Cleaning and polishing agents table) using a red pad*.</p> |

General notes:

- As coatings require regular and cost-intensive basic cleaning and renewal, nora systems GmbH recommends that norament® rubber floor coverings, which are leakproof and have sealed surfaces, not be coated.
- Please observe the instructions in the product and safety data sheets of the cleaning & polishing agents used.

* Suitable pads: 3 M, etc.

** Use single-disk polishing machine with rotation speeds between 300 - 800 rpm (polishing brush) or 1000 - 1500 rpm (polishing pad).
Alternatively, you can also use a high speed machine with rotation speeds between 300 - 800 rpm (polishing pad).

**Should you have any further questions please contact nora Technical Service, www.nora.com
More detailed explanations of the cleaning procedures can be found in our document "Cleaning Definitions".**

Cleaning recommendation norament® 975 LL

Cleaning and polishing agents

The cleaning and polishing agents listed in the table are **recommendations by cleaning agent manufacturers in the German market**. Depending on the premises, it may be useful to use **products and processes that differ from the standard, but according to the cleaning agent manufacturer's recommendation**. Please observe **the product-specific manufacturer's instructions!** Of course, you can also use suitable cleaning agents from non-listed cleaning agent manufacturers according to their recommendations. nora recommends to observe the following list, as from our experience, best results are achieved with these cleaning agents.

| Companies | Initial/intermediate cleaning | Routine cleaning/polishing |
|--|---|---|
| Diversey GmbH 68219 Mannheim Tel. +49 (0)621 / 8757-0 | Taski Combi 800 ml to 8 l water | Taski tensol, 40 ml – 80 ml to 8 l water If necessary, change to Taski 300, 80 ml to 8 l water |
| Dr. Schnell Chemie GmbH 80807 München Tel. +49 (0)89 / 350 608-0 | FLOORTOP 800 ml to 8 l water | FLOORTOP, 40 ml to 8 l water If necessary, change to SCHIROCCO CLEAN, 40 ml – 80 ml to 8 l water |
| Ecolab Deutschland GmbH 40789 Monheim am Rhein Tel. +49 (0)2173 / 599-0 | Maxx Indur 2 800 ml to 8 l water | Maxx Indur 2, 40 ml – 80 ml to 8 l water If necessary, change to Maxx Magic 2, 40 ml to 8 l water |
| Johannes Kiehl KG 85235 Odelzhausen Tel. +49 (0)8134 / 9305-0 | Procur concentrate 200 ml to 8 l water | Procur concentrate, 25 ml to 8 l water If necessary, change to Veriprop, 40 ml to 8 l water (1 dosage) |
| Tana-Chemie GmbH 55120 Mainz Tel. +49 (0)6131 / 964-03 | TAWIP original 800 ml to 8 l water | TAWIP original, 40 ml – 80 ml to 8 l water If necessary, change to TANET extreme, 40 ml – 60 ml to 8 l water |
| KLEEN Purgatis GmbH 32120 Hiddenhausen Tel. +49 (0)5223 / 9970-40 | PREMIUM No 4 800 ml to 8 l water | PREMIUM No 4, 40 ml to 8 l water If necessary, change to SEVERA SKY, 40 ml to 8 l water |
| Dreiturm GmbH 36396 Steinau a. d. Str. Tel. +49 (0)6663 / 970-0 | GOLDREIF Klarwischpflege 200 ml to 8 l water | GOLDREIF Klarwischpflege, 40 ml to 8 l water If necessary, change to MULTINETZER, 40 ml to 8 l water |
| Dr. Schutz GmbH 53175 Bonn Tel. +49 (0)228 / 95352-0 | Floor cleaner R1000 800 ml to 8 l water | Floor cleaner R1000, 40 ml to 8 l water If necessary, change to PU cleaner, 40 ml to 8 l water |
| Buzil-Werk Wagner GmbH & Co. KG 87700 Memmingen Tel. +49 (0)8331 / 930-6 | S 780 Corridor® Daily 800 ml to 8 l water | S 780 Corridor® Daily, 40 ml to 8 l water If necessary, change to R 300 Roca Wipe, 40 ml to 8 l water |