Cleaning Recommendation for transportation norament®



1.	Initial cleaning after installation	Machine wet scrubbing using an active or microfibre pad or a soft scrubbing brush without abrasive fabric content (see Cleaning and polishing agents table).	crub again
2.	Initial polishing treatment/pol- ishing treatment	After the initial or intensive cleaning, evenly apply a suitable wash polish (see Cleaning and polishing agents table) by wet mopping. The dried polishing agent film should be polished** using a polisi a suitable polishing pad*.	hing brush or
3.	Routine cleaning/polish- ing (machine)	Optimal cleaning results are achieved with a scrubber dryer using an active or microfibre pad or a soft scrubbing brush with a suitable wash polish (see Cleaning and polishing agents table).	v .
	Routine cleaning/polish- ing (manual)	Remove dust by using suitable microfibre wipes, mop fleece or dust-binding cloths.	ved by wet
4.	Intermediate cleaning	To remove walking or heel marks and to maintain a uniform and optically appealing look of the floor covering, we recommend cleaning with suitable wash polishes (see cleaning and polishing agents table) using a polishing brush or a suitable polishing pad*.	
5.	Intensive cleaning	Machine wet scrubbing using an active or microfibre pad or a soft scrubbing brush without abrasive fabric content and suitable cleaning agent (see clean- ing and polishing agents table). As water-soluble polishing agents are recom- mended for the polishing treatment, basic cleaning agents are usually not required.	v I

General notes:

- As coatings require regular and cost-intensive basic cleaning and renewal, nora systems GmbH recommends that norament[®] rubber floor coverings, which are leakproof and have sealed surfaces, not be coated.
- Please observe the instruction in the product and safety data sheets of the cleaning & polishing agents used.
- This cleaning recommendation applies to firmly bonded floor coverings.
- * Suitable pads: 3 M etc.
- ** Use single-disc polishing machine with speeds of between 300 800 rpm (polishing brush) or 1000 1500 rpm (polishing pad).

Should you have any further questions please contact nora Technical Service, www.nora.com More detailed explanations of the cleaning procedures can be found in our document "Cleaning Definitions".

Cleaning Recommendation for transportation norament®

Cleaning and polishing agents

The cleaning and polishing agents listed in the table are **recommendations by cleaning agent manufacturers** in **the German market**. Depending on the premises, it may be useful to use **products and processes that differ from the standard, but according to the cleaning agent manufacturer's recommendation**. Please observe **the product-specific manufacturer's instructions**! Of course, you can also use suitable cleaning agents from non-listed cleaning agent manufacturers according to their recommendations. nora recommends to observe the following list, as from our experience, best results are achieved with these cleaning agents.

Companies	Initial machine cleaning after installation	Intensive cleaning	Initial treatment after initial/ intensive cleaning with mop	Manual routine cleaning with 2-step wiping
Diversey GmbH 68219 Mannheim Tel. +49 (0)621 / 8757-0	Intensive cleaner Taski Jontec Best 2 I to 8 I water Exposure time: approx. 10 minutes	Taski forward 400 ml to 8 l water	Taski Combi 800 ml to 8 l water Polishing	Taski 300, 80 ml to 8 l water
Dr. Schnell Chemie GmbH 80807 Munich Tel. +49 (0)89/350 608-0	Basic cleaner TEMPEX ultra 2 to 8 water Exposure time: approx. 10 minutes	SCHIROCCO CLEAN 400 ml to 8 l water	FLOORTOP 800 ml to 8 l water Polishing	SCHIROCCO CLEAN, 40 ml – 80 ml to 8 l water
Ecolab Deutschland GmbH 40789 Monheim am Rhein Tel. +49 (0)2173/599-0	Basic cleaner Bendurol maxx 2.5 to 7.5 water Exposure time: approx. 10 minutes	Maxx Magic 2 160 ml to 8 l water	Maxx Indur 2 800 ml to 8 l water Polishing	Maxx Magic 2, 40 ml to 8 l water
Johannes Kiehl KG 85235 Odelzhausen Tel. +49 (0)8134/9305-0	Basic cleaner Copex 2.5 I to 7.5 I water Exposure time: approx. 10 minutes	Torvan concentrate 100 ml to 8 l water	Procur concentrate 200 ml to 8 l water Polishing	Veriprop, 40 ml to 8 I water (1 dosage)
Tana-Chemie GmbH 55120 Mainz Tel. +49 (0)6131/964-03	Basic cleaner LINAX plus 2.5 I to 7.5 I water Exposure time: approx. 10 minutes	Tanex Primus 400 ml to 8 l water	TAWIP original 800 ml to 8 l water Polishing	TANET extreme, 40 ml – 60 ml to 8 l water
KLEEN Purgatis GmbH 32120 Hiddenhausen Tel. +49 (0)5223/9970-40	POWER STRIP NEUTRA 2 to 8 water Exposure time: approx. 10 minutes	Blue Star Ocean 400 ml to 8 l water	PREMIUM No 4 800 ml to 8 l water	Blue Star Ocean, 40 ml to 8 l water
Dreiturm GmbH 36396 Steinau a. d. Str. Tel. +49 (0)6663/970-0	DURO FIX Express-Basic cleaner Undiluted without exposure time	D1 Neu 400 ml to 8 l water	GOLDREIF Klarwischpflege 200 ml to 8 l water Polishing	MULTINETZER, 40 ml to 8 l water
Dr. Schutz GmbH 53175 Bonn Tel. +49 (0)228/95352-0	Basic cleaner R 2 I to 8 I water Exposure time: approx. 10 Minuten	PU cleaner 400 ml to 8 l water	Floor cleaner R1000 800 ml to 8 l water Polishing	PU cleaner, 40 ml to 8 l water
Buzil-Werk Wagner GmbH & Co. KG 87700 Memmingen Tel. +49 (0)8331/930-6	Indumaster® Step IR 16 2 I to 8 I water Exposure time: approx. 10 Minuten	Indumaster [®] Step IR 16 160 ml to 8 l water	S 780 Corridor [®] Daily 800 ml to 8 l water Polishing	R 300 Roca Wipe, 40 ml to 8 l water

nora

by Interface®