

## **General remarks for the installation of nora<sup>®</sup> floor coverings, stairtreads and accessories**

The basis of each floor covering installation is the country-specific standards. Furthermore, the recommendations of the manufacturers of the subfloor preparation materials and adhesives have to be observed.

The following recommendations are product-specific and based on our experience and tests. If in doubt, we recommend individual adhesive tests. We do not have any influence on the correct processing of the materials involved and therefore cannot accept any warranty for the processing result.

Warranty and liability are exclusively based upon our General Terms and Conditions of Delivery and Payment.

Please observe the following recommendations before the installation of nora<sup>®</sup> floor coverings, stairtreads and accessories:

### **A. The Subfloor**

Suitable subfloors are screeds, mastic asphalt, chipboard, plywood etc.

The subfloor must fulfil the requirements of the country-specific standards regarding the readiness for installation.

Raised floor elements, chipboards, plywood etc. must be installed at the same height. In case of renovations, the elements must be re-aligned where required.

The preparation of the subfloor has to comply with the country specific standards as well as the recommendations of the manufacturers of the subfloor preparation materials.

Before installing noraplan<sup>®</sup> the subfloor always has to be levelled.

Stress-free levelling compounds may exhibit a reduced absorbency. This must be taken into account when using dispersion adhesives by modifying the point of time for embedding as the water content in the dispersion adhesive has to be largely absorbed by the air. Non-absorbent subfloors must be levelled at least 3 mm thick; we recommend levelling by the rake method.

Commercially available level compounds suitable for castor-wheeled traffic have to be used. If the floor is going to be subject to heavy traffic (e. g. by fork lifts etc.) the subfloor has to be levelled with high performance levelling compounds which are for example based on polyurethane.

At the time of installation and of adhesive bonding, the subfloor temperature must be at least 15° C. Ensure that the nora<sup>®</sup> floor coverings, stairtreads and accessories have the required subfloor temperature. Especially in winter time, the material has to be stored on site for several days.

### **B. Material inspection**

The colour and the batch identity (control number on the packaging label) of the floor covering have to be checked. Electrostatic dissipative or conductive norament<sup>®</sup> and noraplan<sup>®</sup> floor coverings have an "ed" or "ec" imprint on the back. Notices of defects or material replacements are only possible if the goods have not yet been installed. There will be no refund for any additional costs.

### **C. After the installation**

Sand, stones, chippings and sharp-edged objects may damage resilient floor coverings beyond repair. Therefore, it is important to protect the installed nora<sup>®</sup> flooring during the construction and after the bonding of the adhesive, i. e. after approx. 72 hours. For this purpose use an appropriate special material which is permeable to vapor diffusion and can be reused. An appropriate covering of unicoloured nora<sup>®</sup> floorings during the construction phase is mandatory.

### **D. Further information**

nora rubber floor coverings must be stored according to general rules regarding the storage of rubber products.

norament<sup>®</sup> and noraplan<sup>®</sup> floor coverings have arrow markings on the back. Tiles and sheets always have to be installed with the arrows pointing into the same direction.

Castor-wheeled office chairs must be equipped with soft grey rolls (type W). If the floor covering is going to be subject to castor-wheeled traffic, the screed and the process materials used (e. g. levelling compound, adhesive) must be suitable for castor-wheeled traffic.

If installing nora<sup>®</sup> floor coverings on screeds with underfloor heating please observe the country specific standards referring to this. Furthermore, subfloor preparation materials with the appropriate temperature resistant properties have to be used.

Strictly follow the recommendations and processing instructions of the manufacturer of the subfloor preparation materials. If in doubt, confirmation must be obtained from the manufacturer as to whether the material in question is suitable for a particular subfloor.

The installation of nora<sup>®</sup> floor coverings is not equivalent to a mandatory sealing according to any country specific standard.

### **Contact:**

Contact details, local branches or authorised retailers, as well as other information can be found at [www.nora.com](http://www.nora.com).

E-Mail: [info@nora.com](mailto:info@nora.com)