

Installation recommendation for noraplan® nTx (mineral subfloor, floor on floor)



It is generally assumed that the subfloor is an intact screed floor fulfilling the country-specific standards. Visible defects must be levelled.

noraplan® nTx can also be installed on existing smooth floor coverings (e.g. rubber, linoleum, PVC) as well as on other subfloors (e.g. wood, aluminium). These, however, must be permanently and securely bonded to the subfloor and must not have any cavities. It is therefore necessary that the responsible technician examines the flooring and makes an appropriate recommendation. In floor on floor installation point 3 (Levelling work) is not necessary as a rule.

It is possible to install nora® nTx on heated subsurface constructions without any restrictions, if an appropriate heating protocol is available and the required moisture values are observed.

1. Process the subfloor with the nora® nTx sanding disc (mineral subfloor) or single disc machine (floor on floor) until the surface is smooth and ready to install the new flooring.
2. Vacuum clean the surface.
3. Levelling work:
 - a) Level any unevenness with nora® SF 1001 (or comparable) or, if necessary use nora® SF 1001 (or comparable) for pore sealing.
 - b) If levelling is needed over the whole surface, level nora® L 1000 (or comparable) over the whole surface with a trowel.
 - c) At floor on floor remove damaged areas of the old floor covering and compensate with nora® SF 1001 (or comparable).If the surface of the subfloor is dry, it is necessary to apply nora® PRP 101.
4. After leaving sufficient time to dry, apply nora® nTx 020 **thinly** using a short pile roller (**avoid puddling at all costs**).
5. After leaving sufficient time to dry (approx. 60 min. at 20° Celsius and approx. 50% rel. air humidity) re-sand the entire surface with a single disc machine.
6. Vacuum clean the surface.
7. Lay the complete surface with sheets of noraplan® nTx. Carry out the installation including seam cutting, as described in the installation recommendation for noraplan® (this can be found on our website).
8. Fold back half of the sheets.
9. Remove the protective film from the rear of the sheet and turn down approx. 10 cm. in the overlap area and push it under the folded back flooring. When doing this, make sure that there are no particles of dirt on the adhesive layer.
Tip: Do not scrunch the protective film remnants into a ball, lay the pieces on top of each other and then when the job is finished, roll it together. This minimises the amount of waste!
10. Vacuum clean the surface and insert the sheets.
11. Rub/roll on the flooring
12. For the remaining areas proceed as described in points 8 - 11



noraplan® nTx can be sealed with nora® hot welding rod or nora® 1-C joint sealing compound.

Installation recommendation for norament® nTx (mineral subfloor, floor on floor)

It is generally assumed that the subfloor is an intact screed floor fulfilling the country-specific standards. Visible defects must be levelled.

norament® nTx can also be installed on existing smooth floor coverings (e.g. rubber, linoleum, PVC) as well as on other subfloors (e.g. wood, aluminium). These, however, must be permanently and securely bonded to the subfloor and must not have any cavities. It is therefore necessary that the responsible technician examines the flooring and makes an appropriate recommendation. In floor on floor installation point 3 (Levelling work) is not necessary as a rule.

It is possible to install nora® nTx on heated subsurface constructions without any restrictions, if an appropriate heating protocol is available and the required moisture values are observed.

1. Process the subfloor with the nora® nTx sanding disc (mineral subfloor) or single disc machine (floor on floor) until the surface is smooth and ready to install the new flooring.
2. Vacuum clean the surface.
3. Levelling work:
 - a) Level any unevenness with nora® SF 1001 (or comparable) or, if necessary use nora® SF 1001 (or comparable) for pore sealing.
 - b) If levelling is needed over the whole surface, level nora® L 1000 (or comparable) over the whole surface with a trowel.
 - c) At floor on floor remove damaged areas of the old floor covering and compensate with nora® SF 1001 (or comparable).If the surface of the subfloor is dry, it is necessary to apply nora® PRP 101.
4. After leaving sufficient time to dry, apply nora® nTx 020 **thinly** using a short pile roller (**avoid puddling at all costs**).
5. After leaving sufficient time to dry (approx. 60 min. at 20° Celsius and approx. 50% rel. air humidity) re-sand the entire surface with a single disc machine.
6. Vacuum clean the surface.
7. Lay the complete surface with sheets of norament® nTx and cut to size. Make sure the arrows on the back are all pointing in the same direction. Ideally you should start from the centre of the room, so that the flooring has sufficient time to acclimatise.
8. Then likewise pick up the tiles from the centre of the room and either fold the protective film back in half or cut it in half and remove it.
9. Lay the tiles to the edge of the flooring of the adjoining tiles and rub them down, then remove the rest of the protective film and rub it down.
Tip: Do not scrunch the protective film remnants into a ball, lay the pieces on top of each other and then when the job is finished, roll it together. This minimises the amount of waste!
10. Follow this procedure to finish laying the complete room, rub down the flooring and then roller it



norament® nTx can be sealed with nora® 1-C joint sealing compound.